




1) Download, create and install windows 10 VM.

a. Download the Windows 10 installation ISO file




b. In VirtualBox, create a new VM called: "Win10" then apply the following specs:


1. Attach the Windows ISO you downloaded.
2. 4 GB of memory
3. 2 CPUs.
4. 40 GB od Disk Space




C. Run the VM and install Windows 10.




2) Install Guest Editions on your Windows10 VM









- 3) Download, extract, create VM, and import kali Linux VM hard drive.
 - a. Download the latest 64-bit Kalix Linux VM image for Virtual Box




- b. In VirtualBox, create a new VM called: "Kali". Then apply the following specs:
 1. 2 CPUs.
 2. 2 GB of memory
 3. Extract the downloaded file and import the ".vdi" file as a hard drive




c. Run the VM and install Kali Linux.




- 4) In VirtualBox, create a NAT-Network name: “virtualization”, use an IP address range of 10.0.2.0/24, and ensure that DHCP Server is set to Enabled.





- 5) Attach the newly created “Virtualization”: NAT-Network to your kali & Windows network adapters.








- 6) In both operating systems, utilize the ping command to assess connectivity between the virtual machines and Google's DNS server [8.8.8.8] to confirm a functioning Wide Area Network [WAN] connection




7) Install a **Windows Server 2016** operating system
a. Download Windows Server 2016 image





- b. In VirtualBox, create a new VM called: "WinServer" Then apply the following specs:
1. Attach the Window ISO you downloaded.
 2. 4 GB of memory
 3. 2 CPUs
 4. 50 GB of Disk Space











8) Set the name of the Windows server as “Server20”







9) Install Active Directory services on the machine





10) Promote the server to a domain.













11) Rename the Windows 10 client machine as “PC1” and assign the domain to it.










- 12) Create the following OUs on the DC machine: **Developers, IT, QA, HR and Designers**.
 ADD 5 users for each OU. Create the appropriate groups and assign users to them. Add one user from each department to the **Domain Admins** group











- 13) Create a DNS record that will identify the **Windows 10** client machine by the name "Client-A"







- 14) Create the following GPOs:




- Set a different wallpaper for each department.











- Prevent the QA department's users from accessing the **Control Panel**



- Prevent the HR department's users from accessing the CMD





15) Configure the system to lock out users after failed login attempts. Only the administrator will be able to unlock the user account

Group Policy Management

File Action View Window Help

lockout Policy

Scope Details Settings Delegation

Links

Display links in this location: server20.local

The following sites, domains, and OUs are linked to this GPO:

Location	Enforced	Link Enabled	Path
server20.local	No	Yes	server20.local

Security Filtering

The settings in this GPO can only apply to the following groups, users, and computers:

Name
Authenticated Users

Add... Remove Properties

WMI Filtering

This GPO is linked to the following WMI filter:

SERVER20 34 Warning Disk System 4/30/2025 5:01:33 PM

SERVERS

Group Policy Management Editor

File Action View Help




Computer Configuration Policies Software Settings Windows Settings Name Resolution Policy Scripts (Startup/Shutdown) Deployed Printers Security Settings Account Policies Account Lockout Policy Kerberos Policy Local Policies Event Log Restricted Groups System Services Registry File System Wired Network (IEEE 802.3) Policies Windows Firewall with Advanced Security Network List Manager Policies Wireless Network (IEEE 802.11) Policies Public Key Policies Software Restriction Policies


Policy Setting

Account lockout duration Not Defined

Account lockout threshold Not Defined

Reset account lockout counter after Not Defined





16) Create a shared drive named “Files” that will only be accessible to users of the Designers and Developers department

